

Yamaha Performance Patch Installation

Quick Start Guide for PSR-I610 / PSR-E583

Install New Performance Patches in 5 Minutes


Load your USER FILES from USB and start playing instantly.

1. Copy User Files in USB

Copy the "USER FILES" folder on the USB flash drive


2. Connect USB

Insert into USB TO DEVICE port. Make sure that **USB** is shown (lit continuously) in the upper right of the display.



3. Open File Menu

Hold SHIFT and press FUNCTION to open File Control display



4. Load User File


Select "Load User" using VOICE dial.



5. Confirm Load

While holding [SHIFT], press [+ / YES] again.
The display will show:

"Load OK?"



6. Execute Load Operation

Press the [+ / YES] button to execute the Load operation.
This confirms the loading operation.



7. Exit and Play the Performance Patch

Press [SHIFT] to exit the File Control display.

Then:

- Select the Bank and Registration Memory buttons to load Performance patch

Note:

- Loading a User file overwrites all existing data, including all 10 User Songs, User style data, User chord progression data, all Registration Memory settings, and all Looper data. To keep important data, save it as a separate file onto a USB flash drive before loading.
- Switch on the "Style Freeze" Setting to keep the style unchanged when switching between different Registration Memories.