

List of Android device confirmed to work with Smart Pianist

Brand	Device Name	Model Number	OS
Google	Nexus 5X	-	8.1
Google	Nexus 6P	-	8.1
Google	Pixel	-	8.1
Google	Pixel XL	-	8.0
Google	Pixel 2	-	8.1
Google	Pixel 2 XL	-	8.1
Google	Pixel C	-	8.1
Samsung	Galaxy S9	SM-G960U1	8.0
Samsung	Galaxy S9 Plus	SM-G965U1	8.0
Samsung	Galaxy S8	SM-G9500	7.0
Samsung	Galaxy S8	SM-G950FD	8.0
Samsung	Galaxy S8 Plus	SM-G9550	7.0
Samsung	Galaxy S8 Plus	SM-G955FD	7.0
Samsung	Galaxy S7	SM-G930F	7.0
Samsung	Galaxy S7	SM-G930U	7.0
Samsung	Galaxy S7 Edge	SC-02H	7.0
Samsung	Galaxy S7 Edge	SM-G935FD	7.0
Samsung	Galaxy S7 Active	SM-G891A	7.0
Samsung	Galaxy S6	SM-G920F	6.0.1
Samsung	Galaxy S6 Edge	SCV31	7.0
Samsung	Galaxy S6 Edge Plus	SM-G928A	7.0
Samsung	Galaxy S6 Active	SM-G890A	7.0
Samsung	Galaxy Tab S3	SM-T820	7.0
Samsung	Galaxy Tab S2 8.0	SM-T713	7.0
Samsung	Galaxy Tab S2 8.0	SM-T710	6.0.1
Samsung	Galaxy Tab S2 9.7	SM-T813	7.0
Samsung	Galaxy Tab S2 9.7	SM-T810	7.0

Compatible from Smart Pianist v1.0.1
Compatible from Smart Pianist v1.0.1

*Device compatibility may vary depending on the region or service provider.

*Some of the device listed above might not be sold in some countries.

*The specification of the Android devices listed above is subject to change for certain reasons of manufacturers.

Please note that they may not operate properly with Smart Pianist depending on the changes. For detailed specification and information on the Android devices listed above, please contact the manufacturers of them.