

PSR-SX600

Symphonic Music (Russian Classical

STYLE

Style Name		Style Type
1	Symphonic Waltz	Normal
2	Strings Allegro	Normal
3	Symphonic Allegro	Normal
4	Pastoral Waltz	Normal
5	Andante 6-8	Normal
6	Andante 12-8	Normal
7	Hungarian Dance	Normal
8	Allegro 6-8	Normal
9	Classical Adagio	Normal
10	Baroque Vivace	Normal
11	Baroque Adagio	Normal
12	Baroque 3-4	Normal
13	Mid Tempo Waltz	Normal
14	Symphonic Polka	Normal
15	Symphonic March	Normal
16	Polonaise	Normal
17	Minuetto	Normal
18	Siciliano	Normal
19	Elec Free Play 1	Normal
20	Elec Free Play 2	Normal