

ELA-1

# Church Organ

## VOICE

#	Voice Name	Voice Type	Voice Number		
			MSB#	LSB#	Prg#(1)
1	Org Bourdon 8'	Regular	49	8	11
2	Org FluteChorus1	Regular	49	8	1
3	Org Cornet	Regular	49	8	6
4	Org Prinzipal	Regular	49	7	2
5	Org Pleno	Regular	49	8	4
6	Org Tutti	Regular	49	7	1
7	ClassOR Flute 1	Regular	49	8	34
8	ClassOR Prinz	Regular	49	8	37
9	ClassOR Pleno	Regular	49	8	38
10	ClassOR Tutti	Regular	49	8	40
11	Harmonium Single	Regular	49	8	8
12	Harmonium Dble	Regular	49	7	3
13	Harmonium Trpl	Regular	49	8	10
14	Positif 8' 4'	Regular	49	8	18
15	Positif 8' 2'	Regular	49	8	19
16	Positif Even	Regular	49	8	20
17	Org Chapel 1	Regular	49	8	14
18	Org Chapel 2	Regular	49	8	15
19	Org Chapel 3	Regular	49	8	16
20	Org Chapel 4	Regular	49	8	17
21	Bourdon-Flute	Regular	49	8	28
22	Bourdon-Chapel1	Regular	49	8	29
23	Prinzipal-Flute	Regular	49	8	31
24	Prinzipal-Cornet	Regular	49	8	32
25	Flute+ClarinetMW	Regular	49	8	21
26	Prinz+ClarinetMW	Regular	49	8	22
27	Prinz+Scharff MW	Regular	49	8	23
28	Pleno+Scharff MW	Regular	49	8	25
29	Bourdon+Scharff	Regular	49	8	13
30	Bourdon+Trumpet	Regular	49	8	12

## STYLE

#	Style Name	Style Type
1	1 OrganPlay 1	Normal
2	2 OrganPlay 2	Normal
3	3 OrganPlay 3	Normal
4	4 Choir&Guitar	Normal
5	5 Strings&Harpsi	Normal

## REGIST

#	Registration Name
1	ChurchOrgan1
2	ChurchOrgan2

## DEMO

Demo Name
Church Organ