

PSR-SX920 & SX720

Indian Entertainer

VOICE

	Voice Name	Voice Type	Voice Number		
			MSB#	LSB#	Prg#(1)
1	60s	Regular	51	0	50
2	Film Accordion	Regular	51	0	51
3	Film Brass	Regular	51	0	52
4	Film Flute	Regular	51	0	53
5	Film Trumpet	Regular	51	0	54
6	Film Violin	Regular	51	0	55
7	Film Mandorin	Regular	51	0	56
8	Sitar +	Regular	51	0	46
9	Veena +	Regular	51	0	47
10	Sarod +	Regular	51	0	48
11	Violin +	Regular	51	0	49
12	Super Sitar	Regular	51	0	1
13	Nadaswaram	Regular	51	0	2
14	Veena	Regular	51	0	3
15	Sitar 1	Regular	51	0	4
16	Sitar 2	Regular	51	0	5
17	Studio Veena	Regular	51	0	6
18	Studio Sitar	Regular	51	0	7
19	Bansuri +	Regular	51	0	8
20	Kashmir Santoor	Regular	51	0	9
21	Studio Santoor	Regular	51	0	10
22	Bansuri 1	Sweet!	51	0	11
23	Heavenly Bansuri	Regular	51	0	12
24	Bansuri 2	Regular	51	0	13
25	Slow Bansuri	Regular	51	0	14
26	Harmonium Single	Regular	51	0	15
27	Harmonium Double	Regular	51	0	16
28	Harmonium Triple	Regular	51	0	17
29	Bulbul Tarang	Regular	51	0	18
30	Silver Sarod	Regular	51	0	19
31	Ambient Sarod	Regular	51	0	20
32	Super Shehnai	Regular	51	0	21
33	Shehnai	Regular	51	0	22
34	Sarangit Soul	Regular	51	0	23
35	New Tanpura	Regular	51	0	24
36	Electro Tanpura	Regular	51	0	25
37	Pungi	Regular	51	0	26
38	Ek Tara	Regular	51	0	27
39	Snake Charmer	Regular	51	0	28
40	East Rabab	Regular	51	0	29
41	New Indian Kit 3	SFX	126	1	108
42	New Indian Kit 4	SFX	126	1	109
43	New Indian Kit 1	SFX	126	1	110
44	New Indian Kit 2	SFX	126	1	111
45	Tabla Kit 1	SFX	126	1	112
46	Indian Kit 1	SFX	126	1	113
47	Indian Kit 2	SFX	126	1	114
48	Tabla Kit 2	SFX	126	1	115
49	C Tabla	SFX	126	1	116
50	Db Tabla	SFX	126	1	117
51	D Tabla	SFX	126	1	118
52	Eb Tabla	SFX	126	1	119
53	E Tabla	SFX	126	1	120
54	F Tabla	SFX	126	1	121
55	F# Tabla	SFX	126	1	122
56	G Tabla	SFX	126	1	123
57	Ab Tabla	SFX	126	1	124
58	A Tabla	SFX	126	1	125
59	Bb Tabla	SFX	126	1	126
60	B Tabla	SFX	126	1	127
61	Indian Kit(Taal)	SFX	126	1	128

STYLE

Style Name	Style Type
001 Slow Ballad 2	Normal
002 Gazal 1	Normal
003 Lavni Dance	Normal
004 Mountain Folk	Normal
005 Folk Hills 2	Normal
006 The Beat	Normal
007 Gold 1	Normal
008 Gold 2	Normal
009 Gold 3	Normal
010 Gold Club	Normal
011 Taal	Normal
012 Folk East	Normal
013 Dhol Rock	Normal
014 Duff Mix	Normal
015 Gazal 2	Normal
016 Classical Rock	Normal
017 Love Song 3	Normal
018 Dub Beat	Normal
019 Dance Rock	Normal
020 Tabla Waltz	Normal
021 Sun Dance 2	Normal
022 South Dance 3	Normal
023 South Dance 4	Normal
024 Sun Dance 1	Normal
025 Khemta	Normal
026 Rumba Slow	Normal
027 UK Punjabi	Normal
028 Up Dance	Normal
029 Folk Hills 1	Normal

REGIST

Regist Name	
1 Entertainer	Film Piano
	Film Guitar
	Stage Strings 1
	Stage Strings 2
	Dark Strings
	Solo 1
	Solo 2
	Dream