

PSR-SX920&amp;SX720

**Nuevo Worship Latino 2****VOICE**

Voice Name	Voice Type	Voice Number		
		MSB#	LSB#	Prg#
TrompetaMariachi	Regular	50	2	49
TrompetaMariachiMega	Regular	50	2	58
AcordeónNorteño	Regular	50	2	56
PercKitCumbia	SFX	62	24	91

**STYLE**

Style Name	Style Type
1 RockTensión	Normal
2 BaladaBachata	Normal
3 CumbiaAlegre	Normal
4 RockReggaeton	Normal
5 JúbiloModerno	Normal
6 Aleluya6-8	Normal
7 BaladaEnergética8bt	Normal
8 BaladaEnergética6-8	Normal
9 WorshipCountryPop	Normal
10 WorshipMerengue	Normal
11 AdoraciónFunk	Normal
12 RockDobleTiempo	Normal
13 CumbiaJubilosa	Normal
14 Funky16bt	Normal
15 WorshipMerengueRápido	Normal
16 BaladaRockTensión	Normal
17 BaladaDramática8bt	Normal
18 BaladaAdoración12-8	Normal
19 BaladaPiano16bt	Normal
20 BaladaPop6-8	Normal

**MULTI PAD**

Name
1 LoopsAcordeón1
2 LoopsAcordeón2
3 LoopsAplausos1
4 LoopsAplausos2
5 LoopsCencerro1
6 LoopsCencerro2
7 LoopsClave1
8 LoopsClave2
9 LoopsClave3
10 LoopsClave4
11 LoopsClaveCencerro1
12 LoopsClaveCencerro2
13 LoopsCumbia1
14 LoopsCumbia2
15 LoopsPandereta1
16 LoopsPandereta2
17 LoopsPianoEléctrico1
18 LoopsPianoEléctrico2
19 LoopsToms1
20 LoopsToms2
21 TomsManuál1
22 TomsManuál2
23 AdoraciónFunk
24 Aleluya6-8
25 BaladaAdoración12-8
26 BaladaBachata
27 BaladaDramática8bt
28 BaladaEnergética6-8
29 BaladaEnergética8bt
30 BaladaPiano16bt
31 BaladaPop6-8
32 BaladaRockTensión
33 CumbiaAlegre
34 CumbiaJubilosa
35 Funky16bt
36 JúbiloModerno
37 RockDobleTiempo
38 RockReggaeton
39 RockTensión
40 WorshipCountryPop
41 WorshipMerengue
42 WorshipMerengueRápido

**REGIST**

Regist Name
1 AdoraciónFunk+Aleluya6-8
2 B.Adoración12+B.Dramática8Bt
3 B.Bachata+WorshipCountryPop
4 B.Energética6+8&B.Energ8Bt
5 BaladaPop6-8+B.RockTensión
6 CumbiaAlegre+CumbiaJubilosa
7 Funky16Bt+JúbiloModerno
8 RockDoble+RockReggaeton
9 RockTensión+BaladaPiano16bt
10 W.MerengRápido+W.Merengue
11 PianoPadsTecladoCompleto

**PLAYLIST**

Name
1 PlaylistNuevoWorshipLatino2

**DEMO SONG**

Name
1 DemoNuevoWorshipLatino2