


# STEREO PAIR

You can use two WX-010 units to reproduce stereo sound by setting each speaker as the right or left speaker.

Set the left and right speakers separately by following the steps below.



## Note

- To use the Stereo Pair function, you need two WX-010.
- Stereo Pair is available only when the Network Standby of the unit is enabled (☞ P.16).

## Setting/Playing back music

### 1 Connect each WX-010 to the same network by using the dedicated app “MusicCast CONTROLLER.”

If the WX-010 is linked to another MusicCast unit, first disconnect the link by using the dedicated app “MusicCast CONTROLLER.”

### 2 Tap (power)/CONNECT of each unit to set them to standby.

### 3 Tap and hold the following together for 3 seconds to set the left/right speakers.

- ① For setting the left speaker: and

Indicators light from right to left repeatedly (refer to (A) of the table), and the unit enters pairing standby.



- ② For setting the right speaker: and

Indicators light from left to right repeatedly (refer to (B) of the table), and the units start pairing.



## Indicator display during the Stereo Pair

Stereo Pair status	Indicator display
Start Pairing/ Checking the Left and Right Speaker	<p>(A) Left speaker      (B) Right speaker</p> <p>Right-to-Left      Left-to-Right</p>
Pairing Completed	<p>(C)</p> <p>Center to both sides</p>

After pairing is completed, the indicators light from the center to both sides (refer to (C) of the table), and all indicators return to the normal status.

### 4 Use the dedicated app “MusicCast CONTROLLER” to play back.



- You can check which speaker is the left or right speaker with the dedicated app “MusicCast CONTROLLER” (Indicators light as (A) or (B) of the table).
- In Stereo Pair mode, you can operate one speaker to simultaneously turn off both speakers or adjust the volume of both speakers.
- If about five minutes passes while the unit cannot find the other speaker to connect to, the pairing standby will be cancelled automatically.
- When in Stereo Pair mode, the option settings other than “Initialize the unit.” (☞ P.16) cannot be set.

## Note

The Stereo Pair setting remains even if the speakers enter standby or the power cable is unplugged and plugged again.

## Canceling Stereo Pair

- 1 Tap  (**power**)/**CONNECT** to set the left and right speakers to the standby.
- 2 Tap and hold  (or ) and  on either speaker together for 3 seconds.

Indicators light from both sides to the center and Stereo Pair will be canceled.

Indicator display



Both sides to center

### Note

- The Stereo Pair can be canceled only during standby.
- If you cancel Stereo Pair with one of the two speakers, the other one will be canceled automatically.
- If one of the two speakers is disconnected from the network when canceling the Stereo Pair, cancel Stereo Pair on each speaker.