

Previous DZR / DXS XLF Series Firmware version information

V1.1.1

Additional Function

- Added a MONITOR mode to the D-CONTOUR on DZR315.

Specification Changes

- Now displays a message that a USB flash drive is not connected when selecting UPDATE FIRMWARE without connecting a USB flash drive in updating the firmware.
- The [LIMIT] indicator now turns on during the execution of “Initializing to default settings when you have forgotten your PIN code, etc.”

CAUTION

Make sure not to turn off the power switch while the [LIMIT] indicator remains lit.

- The audio is now muted until all the loading is completed when RESTORE FROM USB is selected on the DEVICE BACKUP screen.

Fixed Bugs

- Solved a problem in which tiny audio skips happen when the FREQ parameter value is changed under the situation that EQ is set to ON and GAIN is set to 0.0 dB on the EQ screen.
- Solved some other minor problems.